

### FEATURES

Front

Rear



### KEY

- |    |  |
|----|--|
| 1. | Kensington lock.   |
| 2. | USB 3.2 gen 2 Type-A.  |
| 3. | USB 2.0 Type-A.  |
| 4. | 12 -24VDC rear jack.   |
| 5. | 2x HDMI 2.0a.  |
| 6. | Intel® i219-LM 10/100/1000 Mbps RJ45 Ethernet (Outside Network). |
| 7. | 2x USB 3.2 gen 2 Type-A.   |
| 8. | 2x USB 2.0 Type-A.   |
| 9. | Intel® i211-AT 10/100/1000 Mbps RJ45 Ethernet (Inside Network).  |

### DEFAULT SETTINGS

Mode	Inline bridge – passive monitoring between Ethernet ports 6 and 9.
Bridge	Bro
Interface 1	Enp1s0 (port 9 – Inside Network)
Interface 2	Enpos31f6 (port 6 – Outside Network)
Hostname	sniffa-s2
Management IP	192.168.1.140/24 on Bro
Default Gateway	192.168.1.254
DNS Server	8.8.8.8
Sniffa Manager IP	192.168.1.210
Syslog Server IP	192.168.1.210
Syslog Port	514
Admin User	<i>sniffaadmin</i>
Admin Password	*****
Operating System	Ubuntu Server – Version 24.04.2 LTS
Added Software	Snort™, Suricata™, Zeek™, Wireshark™ and NeoRouter™

## INCLUDED ACCESSORIES

1. UK Power Supply.



2. 2 x Ethernet Cables.



3. VESA Mounting Plate.



4. Getting Started Guide.

Can also found online at:

[www.sniffa.uk/downloads/SniffaSensor-S2-GettingStartedGuide-WebVersion.pdf](http://www.sniffa.uk/downloads/SniffaSensor-S2-GettingStartedGuide-WebVersion.pdf)

[This document]

## GETTING STARTED

1. Connect the UK Power Supply to the Open-Sensor Power inlet.



2. Connect one Ethernet Cable to the OUTSIDE Interface Socket of the Open-Sensor. Connect the other end of the cable to the Outside Network Router or Switch Interface Socket.




3. Connect one Ethernet Cable to the INSIDE Interface Socket of the Open-Sensor. Connect the other end of the cable to the Inside Network Router, Switch, Server or PC Interface Socket.

*Note: This will be the device(s) or network you want to protect.*



4. Configure a Management PC that is physically connected to the INSIDE network to be on the same subnet as the Open-Sensor. Go to IPv4 settings of the connected network interface card to do this.

*Note: Default Management PC IP address is set on the sensor to be 192.168.1.210/24.*




5. Connect to the Open-Sensor on SSH port 22. (e.g. Using Putty). Run commands as necessary (from next page a to f).

*Note: Default Open-Sensor IP address is set to be 192.168.1.140/24.*







Will require a reboot for configuration settings to be made permanent (recommended).

**c. To set the Timezone to UTC**



To see the current Timezone setting, type the following commands at the terminal command line:

```
sniffaadmin@sniffa-s2:~$sudo date
```

Set the Timezone to UTC type the following commands at the terminal command line:

```
sniffaadmin@sniffa-s2:~$sudo dpkg-reconfigure tzdata
```

Select 'Etc' as the Geographic Area.



Select 'UTC' as the Timezone.

Press 'Ok' to save or 'Cancel/Esc' to close dialogue without saving.

#### d. To View Logging

To check if the sensor is logging correctly, type the following commands at the terminal command line:

```
sniffaadmin@sniffa-s2:-$tail -f /var/log/syslog | grep `zeek-`
```


```
root@sniffa-s2-snort:/usr/local/sbin# tail -f /var/log/syslog | grep zeek-
Jul 22 16:11:24 sniffa-s2-snort zeek-dns 1658506269.609384 C0cTDC38zqH9sv4N22 192.168.
F F F 0 - F
Jul 22 16:11:24 sniffa-s2-snort zeek-conn 1658506254.590849 C0cTDC38zqH9sv4N22 192.168.
0 -
Jul 22 16:11:24 sniffa-s2-snort zeek-conn 1658506224.652785 ChiFCh20WYGoOXRns2 192.168.
0 -
Jul 22 16:11:24 sniffa-s2-snort zeek-conn 1658506224.669535 CCXLrq3k090JI4YZi6 192.168.
-
Jul 22 16:11:24 sniffa-s2-snort zeek-conn 1658506224.784982 CRD1sh17NuysgWYXn7 192.168.
0 -
Jul 22 16:11:24 sniffa-s2-snort zeek-conn 1658506224.790393 C2udLi21TgFa7HOLNd 192.168.
-
Jul 22 16:11:25 sniffa-s2-snort zeek-conn 1658506225.350646 CTeAas2pExFa71sd4 192.168.
0 -
Jul 22 16:11:25 sniffa-s2-snort zeek-conn 1658506225.391985 CWTY1NfHU7LY1E1g 192.168.
-
Jul 22 16:11:25 sniffa-s2-snort zeek-conn 1658506225.452986 Cpuxx0xkEPLHyEr6 192.168.
0 -
Jul 22 16:11:25 sniffa-s2-snort zeek-conn 1658506225.463634 CyvmIj4aWLuW0nJoAa 192.168.
-
```

To stop the tail function, click **Ctrl+c**

#### e. To Clear Logs

To clear the logs, type the following commands at the terminal command line:

```
sniffaadmin@sniffa-s2:-$sudo sniffaclearlogs
```




Press 'Yes' to clear logs or 'No/Esc' to close dialogue without clearing any logs.

#### f. To Reset to Default Settings

To reset the sensor to the default settings, type the following commands at the terminal command line:

```
sniffaadmin@sniffa-s2:~$sudo sniffareset
```



Will require a reboot for configuration settings to be made permanent (recommended)

#### FINISH OFF

6. Buy and Install the Sniffa Sensor Manager Application onto the Management PC that is connected to the INSIDE network.

[Sales@sniffa.uk](mailto:Sales@sniffa.uk)

[www.sniffa-nss.com/products#shop](http://www.sniffa-nss.com/products#shop)

7. To finish off.

- Add an MS SQL Database as required.
- Add the Open-Sensor to the Sensor Manager Application.
- Add an IIS Server and configure the Web Portal.
- Add Users to the Web Portal.
- Set Management PC Time zone to UTC.
- Start Syslog on the Management PC.

*Note: Consult online runbook for instructions.*

[www.sniffa-nss.com/knowledge](http://www.sniffa-nss.com/knowledge)